

TABELLA PIASTRE

PIASTRE	DIMEN. FERR. STAFFE
1	BOVIA 40x44 4x14 4x14
2	" " " " " "
3	BOVIA 40x44 4x14 4x14
4	" " " " " "
5	BOVIA 40x44 4x14 4x14
6	" " " " " "
7	" " " " " "
8	BOVIA 40x44 4x14 4x14
9	" " " " " "
10	BOVIA 40x44 4x14 4x14
11	BOVIA 40x44 4x14 4x14
12	" " " " " "
13	" " " " " "
14	BOVIA 40x44 4x14 4x14
15	" " " " " "
16	BOVIA 40x44 4x14 4x14
17	" " " " " "
18	" " " " " "
19	BOVIA 40x44 4x14 4x14
20	BOVIA 40x44 4x14 4x14
21	" " " " " "
22	" " " " " "
23	BOVIA 40x44 4x14 4x14
24	" " " " " "
25	" " " " " "
26	BOVIA 40x44 4x14 4x14
27	BOVIA 40x44 4x14 4x14

